brake beams newtonents and components WEAR PLATESTORS

Wear Plates

Miner steel side frame wear plates are extremely durable and represent the lowest cost alternative. The only AAR approved steel side frame wear plate.

Connectors

Miner connectors are used to repair damaged freight car brake rods or alter the length of existing brake rods. Connectors act as a splint around the ends of the rods which, when welded into place, form a joint that has the full strength of the original rod. The tapered ends of the connectors reduce the risk of hang-up on a carrier or structural member.

- Cost effectiveness through the salvage of usable materials
- Cuts excessive inventory of replacement rods
- Fast and easy to apply at a low unit cost
- Available in 3/4, 7/8 and 1-1/8 inch sizes





Long-lasting, Trouble-free Performance.

